



Teletype GPS Technical Note

How to Check the Version Number of Your WorldNav Software

Follow the instructions below to check the version number of your WorldNav software. This will allow you to see if you have the latest version of WorldNav.

Note: Before following this procedure, please check to see that the secure digital (SD) card is properly inserted into the GPS.

- 1) First, insert your SD card into your device. From the Main Menu, click “Navigation”:




(Note: On other devices this screen may look different; the “Navigation” button may also read “GPS”.)

- 2) This will take you to a screen that asks you to click a button that says “I Agree”. Do not click this button yet.



- 3) On the lower-right corner of the screen, you will see a series of letters and numbers. This is the version number of your software.



- 4) You can contact TeleType with this number to find out if you have the latest version of your software. If your software is out of date, you will have the option of upgrading.

TeleType * 44 School Street * Boston, MA 02108
617-542-6220 * 1-800-717-4478 * contact@teletype.com //